

Our [post base trim](#) comes pre-assembled, with three sides joined together and a separate fourth side.

To install, follow these two easy steps.

1. apply an exterior-grade construction adhesive to the inside of the three-sided section and slide it firmly around the post
2. apply an exterior-grade construction adhesive to the inside of the remaining piece and slide into place

